



Service Bulletin

SB: 20200515

SUBJECT: START UP OF OVENS AND PROOFERS

ISSUES COVERED: PROCESS

Steps to restart after temporary disconnect of equipment.

OVEN/PROOFER START UP

- **Step 1:** Inspect unit for any damage . Check for any leaks or standing water inside the oven cavity. Check the water connections at the back of the oven/proofer to ensure they are not loose or leaking.
- **Step 2:** Clean the interior of the oven cavity with a mild detergent solution. DO NOT use harsh abrasive scouring pads or abrasive detergents as they could damage the oven. Ensure that any detergent or cleaning material has been completely removed after each cleaning.
- **Step 3:** Thoroughly clean the exterior surfaces of the oven with, a damp cloth moistened with a mild detergent solution. Baked on deposits or discoloration may require a good quality stainless steel cleaner. Always apply cleaner when the oven is cold and rub in the direction of the grain.
- **Step 4:** Plug the unit in to a dedicated wall outlet. Each oven should be connected to an adequately protected power supply with an appropriate three wire power cord.
- **Step 5:** For first time use of the oven after being disconnected, operate the oven for about 1 hour at 200°C / 400°F to remove any fumes or odors which may be present. Please refer to the Operation Section of your manual for details on how to correctly operate and shutdown the oven.

If you need additional support , please contact

Technical Service: 866-673-7937